

# 222

## TEAK CLEANER POWDER



### Description

- Economical solution for cleaning and degreasing teak decks.
- Formula without strong acids or solvents. Its dosage will allow both: a standard cleaning or a heavy duty cleaning.

### Product information

<b>Composition</b>	Contains trisodium phosphate dodecahydrate.
<b>Appearance/ Odour</b>	Hygroscopic powder / odorless
<b>pH</b>	11.7 - 12 12.5
<b>Density</b>	N.A
<b>Flash point</b>	N.A
<b>Transport N° ONU</b>	N.A
<b>Storage</b>	Store in the original container in a dry, cool and well ventilated area.
<b>Packaging</b>	1kg pot / 5kg bucket

### Directions for use

<b>Compatibility / supports</b>	Teak
<b>Méthodes</b>	<ul style="list-style-type: none"> <li>- Classic Maintenance: 150-200 g of powder for approximately 10 liters of water, in other words, a dosage of 2%.</li> <li>- To revive and clean deeply: Double the dose.</li> <li>- Wet the deck and hull to avoid stains. Apply the product with a soft brush, rubbing vigorously across the wood fiber for better results. Leave for 15 to 20 minutes and rinse with clear water (if possible with some pressure) while brushing to remove the last impurities.</li> <li>- Avoid direct sunlight and applying on extremely hot days.</li> </ul>

**SAFETY DATA SHEET  
AVAILABLE ON REQUEST**

Always refer to the descriptions on labels. Keep out of reach of children. Respect the conditions of use.

### Precautions for use

- Causes skin irritation. Causes serious eye irritation. May cause respiratory irritation. Before use: Always perform a test in a corner and in a small area. Avoid inhaling vapors, fumes, gases, and dust.



**Warning**